

BL-ICE1000

USER MANUAL

Introduction

Thank you for choosing this BL-series fog machine. You now own a rugged and powerful state-of-the-art machine. Prior to use, we suggest that you carefully read all of the instructions.

By following the suggestions found in this user manual, you can look forward to the reliable and satisfactory performance of your fog machine for years to come.

I. Specifications:

VOLTAGE:	110V/60HZ, 230V/50HZ
POWER:	1000W
FUSE:	125V/10A, 250V/5A
WARNING UP TIME	5MIN
SPRAY DISTANCE:	5M
OUTPUT:	15000 CUFT/MIN
TANK CAPACITY:	1.5L
SIZE:	L415XW217XH145MM
WEIGHT:	8.0KG

Attached Controller

ON/OFF remote (10 meter cable): include

ON/OFF remote (wireless two-band receiver and transmitter/30 meter range): optional

Timer remote (timer, manual or continuous output/10 meter cable): optional

Please follow these operation, safety and maintenance instructions to ensure a long and safe life for your fog machine.

CAUTION

Danger of electric shock

- Keep this device dry.
- For indoor only. Not designed for outdoor use.
- Use 3-prong grounded electrical outlet only. Prior to use take care to determine that the unit is installed at the rated voltage.
- Always unplug your fog machine before filling its tank.
- Keep fog machine upright.
- Turn off or unplug when not in use.
- This machine is not water-or splash- proof. If moisture, water, or fog liquid gets inside the housing, immediately unplug the unit and contact a service technician or your dealer before using it again.
- No user serviceable parts inside. Refer to your dealer or other qualified service personnel.

DANGER OF BURNS

- For adult use only. Fog machine must be installed out of the reach of children. Never leave the unit running unattended.

- Never aim the output nozzle directly at people.
- Fog machine output is very hot. Avoid coming within 60 cm of the output nozzle during operation.
- Locate the fog machine in a well-ventilated area. Never cover the unit's vents. In order to guarantee adequate ventilation, allow a free air space of at least 20-cm around the sides and top of the unit.
- Never aim the output nozzle at open flame.
- The output nozzle becomes very hot during operation (300 degrees C). Keep flammable materials at least 50 cm away from the nozzle.
- Always allow your fog machine to cool down before attempting to clean or service it.

DANGER OF EXPLOSION:

- Never add flammable liquids of any kind (oil, gas, perfume) to the fog liquid. Pay attention to all warning labels and instructions printed on the exterior of your fog machine.
- Use only the high-quality, water-based fog liquid that your dealer recommends. Other fog liquids may cause clogging or "spitting".
- Always make sure there is sufficient liquid in the fog liquid tank. Operating this unit without liquid will cause damage to the pump as well as over-heating of the heater.
- If your fog machine fails to work properly, discontinue use immediately. Drain all fog liquid from the tank, pack the unit securely (preferably in the original packing material), and return it to your dealer for service.
- Always drain tank before mailing or transporting this unit.
- Never drink fog liquid. If it is ingested, call a doctor immediately. If fog liquid comes in contact with skin or eyes, rinse thoroughly with water.

UNPACKING & INSPECTION:

Open the shipping carton and verify that all equipment necessary to operate the system has arrived intact, refer to "features" section for information on what items are included with your model. If any equipment is missing contact your dealer immediately.

Before initial setup of your fog machine. Make sure that there is no evident damage caused by transportation. In the event that the unit's housing or cable is damaged, do not plug it in and do not attempt to use it until after contacting your dealer for assistance.

SETUP

- Remove all packing materials from shipping box, check that all foam and plastic padding is removed, especially in the nozzle area.
- Place fog machine on a flat surface and remove fog liquid tank cap.
- Fill with fog liquid or other high-quality water-based fog fluid. Any other types of fluid can damage that unit. When filled, place cap back on liquid tank.
- Firmly attach remote control cable to the proper input on the rear of the machine.

OPERATION

- Plug power cord into a grounded electrical outlet. If necessary, turn power switch on rear of unit to "1" position; Warm-up is complete when green lamp lights up on remote unit.
- To emit fog, press the appropriate button on the remote for the desired length of time.

- The remote unit's lamp will cycle on and off as the machine re-heats to the proper operating temperature.
- For further information on operating your Fog Machine, see the section titled, "Remote CONTROL OPERATION".
- If your model includes a mounting bracket designed for overhead installation, it may be installed at floor level or suspended overhead. If the unit is to be mounted using the bracket, it is important that the fog does not shoot directly at any one's face. Whatever installation method you choose, do not allow the unit to have more than a 15 degree angle of inclination.

Important: Always monitor tank fluid level as you are fogging, running a fog machine with no fluid can permanently damage the unit.

If you experience low output, pump noise or no output at all, unplug immediately. Check fluid level, the external fuse, remote connection, and power from the wall, if all of the above appears to be O.K., plug the unit in again. If fog does not come out after holding the remote button down for 30 seconds, check the hose attached to the tank to make sure there is fluid going through the hose. If you are unable to determine the cause of the problem, do not simply continue pushing the remote button, as this may damage the unit. Return the machine to your dealer.

Cleaning your fog machine regularly will help reduce costly parts replacement and repair charges.

Maintenance

Do not allow the fog liquid to become contaminated. Always replace the caps on the fog liquid container and the fog machine liquid tank immediately after filling.

After every 40 hours of continuous operation. It is recommended to run a cleaning solution composed of 80% distilled water 20% white vinegar through the system to prevent the accumulation of particulate matter in the heating element. The recommended-cleaning regimen is as follows:

1. White unit is unplugged and cool, unscrew nozzle at very front of unit and clean out debris with vinegar and a pipe cleaner, making sure that the hole is free of clogs.
2. Empty all fog fluid from machine. Add cleaning solution to tank. Plug unit in and begin warm up.
3. Run unit in a well-ventilated area until tank is empty.
4. Replace nozzle.
5. Cleaning is now complete, refill with fog liquid.

Note: all fog machines are prone to clogging due to the thick consistency of fog fluid and the high temperature at which it vaporizes. However, a properly maintained fog machine should provide years of reliable use.

Clean with a dry cloth only.

Store dry.

Save these instructions.